- Connect fixture wires to low voltage wiring (remote LED driver 700mA constant current).
- Attach mounting plate to electrical box.
- Thread C1 canopy to mounting plate.
- Push in jack connector and thread cap until secure.

92mm 3-5/8"	92mm 3-5/8"
•	Standard 4"
	Standard 4" Octagonal Box
	Retrofit Mounting Plate
	C1 Mounting Plate
	C1 Canopy
	Jack Connector
	Сар

(I)	CAUT	LION
(•)	VAVI	

- · Read all instructions.
- WARNING: RISK OF FIRE OR ELECTRICAL SHOCK: Do not make or alter any openings in the compartment of wiring or electrical components during installation. Do not alter or add ballasts, or any other electrical components.
- Installation and use of this fixture mounting assembly requires a person familiar with the construction and operation of luminaire electrical systems and the hazards involved, if not qualified, do not attempt installation.
- Turn off power before installation.
- Fixture gets very hot. Do not cover Keep 9" away from combustible materials.
- 700mA constant current driver only.
- Do not spray water on fixture during cleaning. Avoid using detergents with hand softeners, anti-bacterial agents, glass cleaners or acrylic cleaning products.
- KEEP THESE INSTALLATION INSTRUCTIONS.

Parts	Qty
• LED unit	
 C1 canopy 	
 Cross pan head screws 	
 Mounting plate 	
Wire connectors	

2 1 2

Tools

• Phillips screwdriver not included

Maintenance

Clean using a soft cloth.

[>] MPLIGHTING®

t 1.877.708.1184 f 604.708.1185 www.mplighting.com 16 West 4th Avenue, Vancouver BC V5Y 1G3, Canada

