- Attach mounting plate to cove, wall, shelf or cabinetry with mounting screws (not supplied).
- Connect circuit board rail to mounting plate. Next attach lens to circuit board rail.
- Fasten end-caps into C-shaped screw channels in both sides of circuit board rail. Tighten screws with Allen Key.
- Connect fixture wires to low voltage wiring 24V DC constant voltage drivers with 120-277V input, TLDDLV100W4100).



t1.877.708.1184 f604.708.1185 www.mplighting.com 16 West 4th Avenue, Vancouver BC V5Y 1G3, Canada



CAUTION

- · Read all instructions.
- WARNING: RISK OF FIRE OR ELECTRICAL SHOCK: Do not make or alter any openings in the compartment of wiring or electrical components during installation. Do not alter or add ballasts, or any other electrical components.
- Installation and use of this fixture mounting assembly requires a person familiar with the construction and operation of luminaire electrical systems and the hazards involved, if not qualified, do not attempt installation.
- Turn off power before installation.
- Connect to appropriate 24V DC constant current driver only.
- Do not over tighten screws.
- · Do not spray water on fixture during cleaning. Avoid using detergents with hand softeners, anti-bacterial agents, glass cleaners or acrylic cleaning products.
- KEEP THESE INSTALLATION INSTRUCTIONS.

change.	Mounting Plate
	Screws
99-2011	End Cap
	Circuit Board Rail
↑ CLICK	Lens

Parts

- LED rail
- Cross countersunk screws
- End-caps

Tools

Qty.

4

2

• Phillips screwdriver not included

Maintenance

Clean with a soft cloth.

