Drill a Ø2" (51mm) hole.

Connect fixture wires to low voltage wiring (remote LED driver 350mA or 700mA constant current).

2


To mount with spring, push L501 fixture with friction fit spring clip into Ø2" (51mm) hole until the cover is flat with the surface.




L501 Installation Instructions

🚹 CAUTION

- · Read all instructions.
- WARNING: RISK OF FIRE OR ELECTRICAL SHOCK: Do not make or alter any openings in the compartment of wiring or electrical components during installation. Do not alter or add ballasts, or any other electrical components.
- · Installation and use of this fixture mounting assembly requires a person familiar with the construction and operation of luminaire electrical systems and the hazards involved, if not qualified, do not attempt installation.
- Turn off power before installation.
- Constant current driver only 350mA or 700mA.
- Do not spray water on fixture during cleaning. Avoid using detergents with hand softeners, anti-bacterial agents, glass cleaners or acrylic cleaning products.
- KEEP THESE INSTALLATION INSTRUCTIONS.





Parts

• LED unit w/ spring clip

Qty.

1

Maintenance Clean using a soft cloth.



t1.877.708.1184 f604.708.1185 www.mplighting.com 16 West 4th Avenue, Vancouver BC V5Y 1G3, Canada