


2 Connect fixture wires to low voltage wiring (remote LED driver 700mA constant current).

3

Push LED housing with friction fit spring clip into \emptyset 1-1/2" (\emptyset 38mm) hole until flush with surface.



L67 Installation Instructions



- Read all instructions.
- WARNING: RISK OF FIRE OR ELECTRICAL SHOCK: Do not make or alter any openings in the compartment of wiring or electrical components during installation. Do not alter or add ballasts, or any other electrical components.
- Installation and use of this fixture mounting assembly requires a person familiar with the construction and operation of luminaire electrical systems and the hazards involved, if not qualified, do not attempt installation.
- Turn off power before installation.
- 700mA constant current driver only.
- Do not spray water on fixture during cleaning. Avoid using detergents with hand softeners, anti-bacterial agents, glass cleaners or acrylic cleaning products.
- KEEP THESE INSTALLATION INSTRUCTIONS.

01-2018



Parts



LED unit w/ spring clip



Clean using a soft cloth.



t 1.877.708.1184 f 604.708.1185 www.mplighting.com 16 West 4th Avenue, Vancouver BC V5Y 1G3, Canada

Qty. 1

